


# Compact

## Instructions

Keep for reference



For Advice. For Help. For Repairs:

**+44 (0) 1296 390 390**  
**seriousreaders.com**



The Chapel of Light, Aylesbury Road, Birtton,  
Bucks, HP22 5DW, Great Britain

SR079




# Compact Light

## Getting Started

Your light is ready to plug in and use. The switch is located on the head of the light.


## Tilting

This light is deliberately lightweight. Horizontal extension of the arm will cause it to tilt. Place a weight on the base or adjust the arm to avoid this.



## Flexible Arm

Bend the stay-put flexible arm to direct the light beam.





## Fuse

The plug is protected by a 5 Amp fuse.

## Safety

Please contact us if there is any cable damage. Do not attempt a repair.


**Indoor use only.**



## Changing the Bulb

Disconnect from power and allow to cool. Unscrew the ribbed front shade by rotating anti-clockwise.

The bulb has a bayonet fitting. Twist it anti-clockwise (with the head in the position shown) and pull to remove. Insert the replacement. Screw the shade back into place.



## Replacement Bulbs

The bulb code is **15197A**.

Only use approved bulbs (Max 5W).