

Using Your ROAM Light™

1. Remove the light from the packaging and place flat on a steady surface.
2. The power switch is a touch switch that controls both on/off, and brightness settings.
 - Touch once to turn the light on to the 1st brightness setting (least bright).
 - Touch a second time for the 2nd brightness setting (mid-brightness).
 - Touch a third time for the 3rd brightness setting (brightest).
 - Touch a fourth time to turn the light off.
3. To position the light, hold the light body steady and grasp either the flexible neck or light shade, depending on the adjustment needed.
4. The LED panel might get hot after several hours of continuous use. Turn the light off and wait until the light shade is cool before handling.
5. Do not alter the power adaptor.
6. Indoor use only.
7. The light shade is a sealed unit and cannot be replaced.

Battery and Charging

1. Charge your ROAM Light™ before use – it is shipped uncharged.
2. Connect the USB-C charging cable to the power adaptor, and into the power connector located at the rear of the light body.
3. Only use with the supplied power adaptor to avoid damage or fire.
4. Charge the light using the included USB-C charging cable or power adaptor. It will take approximately 9.5 hours to charge. The LED indicator on the rear of the light will change from red to green when the light is fully charged. Once fully charged, the battery will last approximately 3.5 hours on full brightness.
5. It is safe to use your ROAM Light™ while it is charging.

Battery Replacement

- This light uses a lithium-ion battery. The battery compartment is located on the rear of the light body.
- To replace the battery, use a Phillips screwdriver to remove the screw that holds the battery compartment door in place. Remove the old battery and install a new one with “+” facing upwards. Replace the battery compartment door ensuring that the screw is tightened.

Battery Disposal

- Batteries contain harmful materials, and are classified as hazardous waste. They must never be thrown away with daily rubbish. They should be returned to the manufacturer or your local recycling service for disposal. Do not incinerate.
- Serious Readers® is WEEE registered and provides a disposal service at Unit 15 – 16 Faraday Road, Aylesbury, HP19 8RY.

Product Safety

- If the battery compartment does not close securely, stop using the product.
- Avoid extreme temperatures.
- Use original or certified cables. If the external flexible cable or cord of this luminaire is damaged, it must be replaced by the manufacturer in order to avoid a hazard.
- Do not alter the plug.
- Indoor use only.
- Do not expose to liquids.
- Avoid dropping.
- Do not disassemble.
- Keep new and used batteries away from children.

Specifications

Power: 5W LED	USB Charging Port: 1.0A
Lumens: 270	Input Power: 1.0A
Colour Rendering: Up to 97%	Colour Temperature: 5,000K
LED Lifespan: Up to 40,000 hours	Power Adaptor:
Height: 10.75” – 18.75” (27 – 48cm)	Input: 200-240V, 50/60 Hz.
Weight: 1.1lbs (500g)	0.25A Output: 5.0V DC
Base Size: 2.6” x 3.6” (6.5 x 9cm)	Battery:
	Lithium
	3.7V/3350mAh/12.395Wh

0800 028 1890 | +44 (0) 1296 390390
www.seriousreaders.com

To purchase spare batteries, request a brochure or purchase any light in the Serious Family, please call or visit our website.

Customer Service

Please see the customer service details below.

Replacement batteries are available to purchase from us.

ROAM Light™?

Where can I buy replacement batteries for the ROAM Light™?

The ROAM Light™ is designed to only be used indoors.

Can I use the ROAM Light™ outside?

The energy efficient LEDs are rated to last up to 40,000 hours.

How long do the LEDs last?

The LED panel is a sealed unit and cannot be replaced.

Can I replace the LEDs?

body will change from red to green.

Once fully charged, the LED indicator on the rear of the light body will change from red to green.

charged?

How will I know when the ROAM Light™ is fully charged?

Yes, you can use the light while it is charging.

Can I use the ROAM Light™ while it is charging?

Frequently Asked Questions

REDUCE EYE STRAIN

WARRANTY

1 year

NO ASSEMBLY NEEDED

0800 028 1890

+44 (0) 1296 390390

www.seriousreaders.com

Serious Readers, Chapel of Light, Bierton,
Bucks, HP22 5DW, Great Britain

SR1220

Founder

Alex Pratt OBE

We believe that better light enriches our lives by improving sight and well-being. I hope that you love the ROAM Light™.

We believe that better light enriches our lives by improving sight and well-being. I hope that you love the ROAM Light™.

We hope you will love your new ROAM Light™

Our eyes work best in balanced natural light. The ROAM Light™ uses ClearSun® Technology to closely match daylight, helping you see small print and colours in higher definition. Lightweight and easy to move around, it projects a light pattern that helps you read and work in comfort anywhere in your home.

Congratulations

ROAM


Light™

Instructions


Light up your life indoors™

Using Your ROAM Light™


What's in the box?




Changing the settings



Directing the light beam




The ROAM Light™



Using Your ROAM Light™

Charging the ROAM Light™

Connect the USB-C charging cable to the power adaptor and the light. Plug the power adaptor into a standard household 100V – 240V power outlet. Charge using included USB-C charging cable and power adaptor.




Changing the battery

This light uses a lithium-ion battery. The battery compartment is located on the rear of the light body.

To replace the battery, use a Phillips screwdriver to remove the screw that holds the battery compartment door in place.

Remove the old battery and install a new one with "+" facing upwards. Replace the battery compartment door ensuring that the screw is tightened.



ClearSun is a registered trademark of OttLite Technologies, Inc.